

# TP02G-AS1

## Instruction Sheet

## 安裝說明

Text Panels  
文本顯示器系列  
文本文显示器系列




### Back Panel




5 PIN terminal/Wire gauge: 12-24 AWG/Torque: 4.5 lb.-inch

### Dimension


Front panel (unit: mm [inch])




Right side diagram (unit: mm [inch])



Vertical view (unit: mm)



Mounting dimension (unit: mm [inch])




### Installation

Please insert TP02 series to the opening hole of panel and tighten the screws. However, if a firm mounting TP02 series to the panel is needed, please use the mounting fixed support accessory which is packed together with TP02 series, then insert the fixed support in the back and tighten the screws.

△ If the fixed support is not installed well, Delta will not guarantee the waterproof function. The screw torque should be 4-5(kg-cm). DO NOT exceed this specification when tightening the screws; otherwise TP02 series may be damaged. Please leave sufficient space (more than 50mm) around the unit for heat dissipation.

Notes: The flat surface should be a UL Type 4 "Indoor Use Only" enclosure or equivalent (IP65/NEMA4). Please refer to the figures below.



## Warning

EN TP02G-AS1 is an OPEN-TYPE device. It should be installed in a control cabinet free of airborne dust, humidity, electric shock and vibration. To prevent non-maintenance staff from operating TP02G-AS1, or to prevent an accident from damaging TP02G-AS1, the control cabinet in which TP02G-AS1 is installed should be equipped with a safeguard. For example, the control cabinet in which TP02G-AS1 is installed can be unlocked with a special tool or key.

EN DO NOT connect AC power to any of I/O terminals, otherwise serious damage may occur. Please check all wiring again before TP02G-AS1 is powered up. After TP02G-AS1 is disconnected, Do NOT touch any terminals in a minute. Make sure that the ground terminal is correctly grounded in order to prevent electromagnetic interference.

FR TP02G-AS1 est un module OUVERT. Il doit être installé que dans une enceinte protectrice (boîtier, armoire, etc.) saine, dépourvue de poussière, d'humidité, de vibrations et hors d'atteinte des chocs électriques. La protection doit éviter que les personnes non habilitées à la maintenance puissent accéder à l'appareil (par exemple, une clé ou un outil doivent être nécessaire pour ouvrir a protection).

FR Ne pas appliquer la tension secteur sur les bornes d'entrées/Sorties, ou l'appareil TP02G-AS1 pourra être endommagé. Merci de vérifier encore une fois le câblage avant la mise sous tension du TP02G-AS1. Lors de la déconnexion de l'appareil, ne pas toucher les connecteurs dans la minute suivante. Vérifier que la terre est bien reliée au connecteur de terre afin d'éviter toute interférence électromagnétique.

## Introduction

### Product Outline



### Panel Function Explanation

Panel component	Explanation
Alarm LED indicator (RED)	Status 1: When power is on, LED will blink slowly for three times. Status 2: When there is an abnormal situation, LED will blink quickly along with an alarm sound.
RS-232 LED indicator (yellow)	LED will blink when transmits program and communicates via RS-232.
RS-485 LED indicator (green)	LED will blink when communicates via RS-485.
Displaying area	Liquid Crystal Module display area. It is used to display current program status.
Escape/Exit key	It is used to cancel an incorrect input, or to exit a programming step.
Enter key	It is used to input a value or accept a programming command.
Arrow keys	UP/Pg Up: It is used to increase the value or move up one page. Pg Dn/DOWN: It is used to decrease the value or move down one page. Left: This key is left direction key and it can be used to select the position of the value. Right: This key is right direction key and it can be used to select the position of the value.
Function keys	F0/0: It is used as a constant 0, or the user can define it as function F0. F1/1: It is used as a constant 1, or the user can define it as function F1. F2/2: It is used as a constant 2, or the user can define it as function F2. F3/3: It is used as a constant 3, or the user can define it as function F3. F4/4: It is used as a constant 4, or the user can define it as function F4. F5/5: It is used as a constant 5, or the user can define it as function F5. F6/6: It is used as a constant 6, or the user can define it as function F6. F7/7: It is used as a constant 7, or the user can define it as function F7. F8/8: It is used as a constant 8, or the user can define it as function F8. F9/9: It is used as a constant 9, or the user can define it as function F9.

## Specifications

### Function Specifications

Item	TP02G-AS1
Screen type	STN-LCD
Display color	Monochromatic
Backlight	The back-light automatic turn off time is 1 ~ 99 minutes (0 = DO NOT turn off) (The back-light life is about 50 thousand hours at 25°C)
Resolution	5*8 dots, 25 characters*8 rows 8*8 dots, 16 characters*8 rows 8*12 dots, 16 characters*5 rows 8*16 dots, 16 characters*4 rows
Display range	(W) x (H) = 72 x 22 (unit: mm)
Contrast adjustment	15 levels of adjustment
Language/font	ASCII: Alphanumeric (including European characters) Taiwan: (Big 5 codes) Traditional Chinese Fonts China: (GB2324-80 codes) Simplified Chinese Fonts
Font size	ASCII: 5 x 8, 8 x 8, 8 x 12, 8 x 16
Alarm LED indicator (RED)	1. Power on indication (blink for three times) 2. Communication error alarm 3. Special indication by user programming
RS-232 LED indicator (yellow)	It will blink when transmitting program and communicating by using RS-232.
RS-485 LED indicator (green)	It will blink when communicating by using RS-485.
Program memory	256KB flash memory
RAM of system	32K Byte
External interface	Serial communication port RS-232 (COM1) Data length: 7 or 8 bits, Stop bits: 1 or 2 bits Parity: none/odd/even, Transmission speed: 4,800 bps ~115,200 bps RS-232: 9 PIN D-SUB male Extension communication port RS-485 (COM2) Data length: 7 or 8 bits, Stop bits: 1 or 2 bits Parity: None/Odd/Even, Transmission speed: 4,800 bps ~115,200 bps RS-485: 5 PIN removal terminal Extension interface 1. Update firmware version 2. The slot for program copy card 5 PIN removal terminal Include 24V DC input and RS-485 communication input

### Electrical Specifications

Specifications	TP02G-AS1
Communication interface	COM1: RS-232 COM2: RS-485
Waterproof class of front panel	IP65/NEMA4
Operating temperature for hardware	0 ~ 50°C; 20 ~ 90%RH (non-condensing)
Storage temperature for hardware	-20 ~ 60°C

Specifications	TP02G-AS1
Vibration	5Hz ≤ f < 9Hz = Continuous: 1.75mm / Occasional: 3.5mm 9Hz ≤ f ≤ 150Hz = Continuous: 0.5g / Occasional: 1.0g
Shock	15g peak, 11ms duration, half-sine, three shocks in each direction per axis, on 3 mutually perpendicular axes (total of 18 shocks)
Radiated emission	CISPR11, Class A
Electrostatic discharge immunity	EN61000-4-2
Radiated immunity	EN61000-4-3
Electrical fast transient	EN61000-4-4
Weight/dimensions	0.24kg; 147 × 97 × 35.5mm (Width(W) × Height(H) × Deep(D))
Cooling method	Natural air cooling

## Password Function

- If the user forgot the password, the password can be cleared by using the following code: 8888. This universal code will clear the password and all TP02 series internal programs. The TP02 series will be reset to the factory settings by using this code also. Please pay close attention when using it.
- The password can be the alphabet from A to Z or the number from 0 to 9. But it must use the function keys F0 ~ F9 to input the password characters. Please refer to the following table.  
F0: scrolls in a loop as follows 0→A→B→C→D→E→F→0.  
F1: scrolls in a loop as follows 1→G→H→I→J→K→1.  
F2: scrolls in a loop as follows 2→L→M→N→O→P→2.  
F3: scrolls in a loop as follows 3→Q→R→S→T→U→ V→3.  
F4: scrolls in a loop as follows 4→W→X→Y→Z→4.  
F5: It just can be used to be constant 5.  
F6: It just can be used to be constant 6.  
F7: It just can be used to be constant 7.  
F8: It just can be used to be constant 8.  
F9: It just can be used to be constant 9.

## Hardware Operation

When the user wants to startup TP02 series, a 24V DC power is needed. After applying 24V DC power to TP02 series, it will enter into the startup display and then enter the user-designed program. Pressing Esc key and holding on for 5 seconds can return to system menu. There are five selections in the system menu and are described below.

Selections	Explanation
Download program	Use the connection cable (DVPACAB530) to connect the TP02 serial communication port RS-232 to a PC. Then use the TPEditor software to download an application program to TP02.
Upload program	Use the connection cable (DVPACAB530) to connect the TP02 serial communication port RS-232 to a PC. Then use the TPEditor software to upload an application program from TP02.
Copy program	Transfer a program between two TP02 units. 1: transmit programs; 2: receive programs. When transmit programs and data between two TP02 units. Set one TP02 to "Receive Program" mode and the other TP02 to "Transmit Program" mode. Please use twisted pair wires to connect the two units via the RS-485 ports.


Selections	Explanation
TP02 settings	There are 8 items that used to modify TP02 system settings: 1. Communication protocol: Setting the address of TP02, the control port of PLC, and the communication string for either RS-232 or RS-485. 2. Contrast: Adjust the contrast of LCM display screen. 3. Back-light: adjust the automatic turn off time of LCM. Setting range is 00 ~ 99 minutes. If set to 00, the LCM Back-light will not turn off. 4. Buzzer: Used to set the buzzer sound, normal mode or quiet mode. 5. Language setting: Used to set the displayed language. English, Traditional Chinese, Simplified Chinese or user defined language. 6. Password setting: Used to set, enable, and disable the password function. If the password function is enabled, it will require the user to input a password before entering any system menu. The factory password is 1234. 7. Startup display: Used to select the TP02 startup display. User can select "user defined" to use the file that designed by TPEditor and download to TP02. 8. Comm. indicator: The user can determine if the RS-232 and RS-485 LEDs will blink or not during communication.
PLC connection	There are two methods to connect to PLC: 1. Using TP02 serial communication port (COM1) RS-232: set 8-pin DIP switch to RS-485 mode and connect the cable (DVPACAB215 or DVPACAB230) to program communication IO RS-232C of PLC. 2. Using extension communication port (COM2) RS-485: set 8-pin DIP switch to RS-485 mode and connect 5-pin removal terminal of extension communication port to RS-485 of PLC with twisted pair.
Execution	Execute the internal program that download from TPEditor or transmitted from other TP02 units. When program is in execution, the user can return to system menu by pressing Escape/Exit (Esc) key for 5 seconds.

## Communication Connection

### TP02G may connect to a PC by using connection cable DVPACAB515



### TP02G may connect to a DVP-PLC by using connection cable DVPACAB215/DVPACAB230/ DVPACAB2A30




## 注意事項

- 請在使用之前，詳細閱讀本使用說明書。
- 實地配線，務必關閉電源。
- 本機顯示操作面板防水，但對油污或具腐蝕性之液體不具防護作用，避免以尖銳之物品刮傷面板使用時請注意。
- 本機輸入電源為直流 24V，不可連接於 RS-485 通訊口信號端，否則可能造成嚴重的損壞，因此請在上電之前再次確認電源配線。
- 輸入電源切斷後，一分鐘之內，請勿觸摸內部電路。請勿在上電時觸摸任何端子。
- 本體上之接地端子 務必正確的接地，可提高產品抗雜訊能力。
- 利用原廠包裝附件之固定架，鎖緊面板固定螺絲時，請勿太緊以免造成機殼損壞。

## 產品簡介

### 產品外觀及各部介紹



### 面板功能說明

面板元件	說明
警示指示燈 (紅燈)	狀態一：當啓動電源時，指示燈慢慢開始閃爍三次。 狀態二：當異常狀態發生，指示燈會重複持續亮一秒並發出警報聲。
RS-232 指示燈 (黃燈)	傳送程式及使用 RS-232 通訊時持續閃爍。
RS-485 指示燈 (綠燈)	使用 RS-485 通訊時持續閃爍。
退出/取消鍵	輸入值錯誤時可按此鍵，刪除文字敘述等。
命令操作鍵	UP/Pg Up: 此鍵為向上方向鍵，可作為數值遞增輸入或換至上頁等操作。 Pg Dn/DOWN: 此鍵為向下方向鍵，可作為數值遞減輸入或換至下頁等操作。 Left: 此鍵為左方向鍵，可作為選擇數值位置操作。 Right: 此鍵為右方向鍵，可作為選擇數值位置操作。
輸入鍵	當輸入值確認正確無誤時，即可按下此鍵。
數值鍵及功能鍵	F0/0: 可作為 0 的常數輸入鍵，也可由使用者定義其個別功能 F0。 F1/1: 可作為 1 的常數輸入鍵，也可由使用者定義其個別功能 F1。 F2/2: 可作為 2 的常數輸入鍵，也可由使用者定義其個別功能 F2。 F3/3: 可作為 3 的常數輸入鍵，也可由使用者定義其個別功能 F3。 F4/4: 可作為 4 的常數輸入鍵，也可由使用者定義其個別功能 F4。 F5/5: 可作為 5 的常數輸入鍵，也可由使用者定義其個別功能 F5。 F6/6: 可作為 6 的常數輸入鍵，也可由使用者定義其個別功能 F6。 F7/7: 可作為 7 的常數輸入鍵，也可由使用者定義其個別功能 F7。 F8/8: 可作為 8 的常數輸入鍵，也可由使用者定義其個別功能 F8。 F9/9: 可作為 9 的常數輸入鍵，也可由使用者定義其個別功能 F9。


### 背面介紹




5-Pin 端子座 / 線徑: 12-24 AWG / 扭力: 4.5 lb-inch

### 外觀尺寸


正面圖 (單位: mm)




俯視圖 (單位: mm)



嵌入開孔尺寸 (單位: mm)



右側圖 (單位: mm)



### 安裝方式

人機介面安裝於控制盤的方法，請直接將人機由盤面的正面直接放入即可 (嵌入式)，若要固定更牢固，可再利用原廠包裝附件之固定架，嵌入後蓋直接四端凹槽處固定，並上、下平均鎖緊面板固定螺絲即可，如下圖為正確安裝: (△固定螺絲時請以扭力: 4.5 (kg-cm) 鎖緊，請勿超過此範圍以免破壞面板)

注意: 該安裝的平面必須是要適用 Type 4 室內使用或相等條件的配電盤外殼。

